



Before first use, please carefully read the QRobot's Safety Manual and the bellow installation guide!

QRobot's base installation guide:

- Step 1: Remove the robot from the box.
- Step 2: Gently lay the robot on its back with the feet positioned at the table edge.
- Step 3: Take the base stand and line up the robot's feet to the contoured shape on the base stand.
- Step 4: Take the first screw and line up to the hole in the base stand. Tighten with the enclosed Allen key.
- Step 5: Take the second screw and line up to the position. Tighten fully both screws.
- Step 6: Carefully stand the robot on its feet away from table edge.

